

List of aviation spare parts available to be delivered from surplus Romanian MoD

List no. 182E/10

SPARE PARTS, ASSEMBLIES & SUB-ASSEMBLIES FOR L-29 AIRCRAFT

Crt No.	Items denomination	Qty (pcs.)	Manuf. Year	Remarks
0	1	3	4	5
1	ACCELEROMETER LUN-1722	4	1979	new
2	ACCELEROMETER LUN-1722	4	1979	repairs needed
3	JET NOZZLE 04-976	12	1979	new
4	CAB ALTIMETER UVPD-15U	32	1962	new
5	ALTIMETER VD-20	5	1962	new
6	ALTIMETER VD-20	6	1962	repairs needed
7	TAIL SKID SHOCK STRUT L-29 514.05	12	1974	new
8	PANEL RUBBER SHOCK ABSORBER SD 130-700	4	1974	new
9	BUMPER L-29 503-10-P13	13	1974	new
10	BUMPER L-29 503-P13	1	1974	repairs needed
11	BUMPER L-13.502.03	10	1974	new
12	PLAN CONTROL ASSY HL-29 405 011 set x 2 ea	2	1974	new
13	CONTROL ASSY HL-29 406 01 set x 2 ea	2	1974	new
14	FIN CONTROL ASSY HL-29 403 04	3	1974	new
15	AILERON COUPLING ASSY HL-29 206 01P1	1	1974	new
16	AILERON COUPLING ASSY HL-29 022501P1	2	1974	new
17	DIRECTIONAL ASSY HL-29 41108 P5	3	1974	new
18	OUTER AILERON SUSPENSION ASSY HL-29 20501P2	1	1974	new
19	INNER AILERON SUSPENSION ASSY HL-29 20501P1	1	1974	new
20	RH UNDERCARRIAGE ASSY HL-29 201-60	1	1974	new
21	LH UNDERCARRIAGE ASSY HL-29 201-59	1	1974	new
22	TYRES 400*150 L-29	212	1993	repairs needed
23	OXYGEN DEVICE WITH HOSE KP-23	10	1962	new
24	DEVICE R-842-117	2	1974	new
25	RECONNAISSANCE DEVICE SRO-2 lit. 11	2	1974	new
26	RECONNAISSANCE DEVICE SRO-2 2AN	1	1974	new
27	RECONNAISSANCE DEVICE SRO-2	1	1974	repairs needed
28	RECONNAISSANCE DEVICE SRO-2 lit. BF 2AN	1	1974	new
29	GENERATOR PACKING SPRING 0-9-0081	9	1986	new
30	GENERATOR PACKING SPRING 0-9-0082	9	1986	new
31	FITTING ADS-42	16	1962	new
32	NETWORK PROTECTION AUTOMATIC DEVICE AZP-1MB	2	1984	repairs needed
33	PARACHUTE AUTOMATIC OPENING DEVICE KAP-3P	20	1990	new
34	PRESSURE AUTOMATIC DEVICE WITH FILTER AD-5A	1	1974	new
35	CRANKSHAFT L-29 503.10.21	2	1962	new
36	COUPLING AXLE 25-06-00-098	3	1986	new
37	COUPLING AXLE 25-06-00-103	4	1986	new
38	CONNECTING AXLE 25-06-00-141	1	1986	new
39	AXLE HL-29 105.0665	1	1962	new
40	AXLE HL(XL)-29 303.09.02R	20	1962	new
41	FRONT WHEEL AXLE L-29 503.10.66	5	1986	new
42	WHEEL AXLE L-29 501.10.205	3	1986	new
43	TRANSMISSION AXLE 25-21-01-188	6	1986	new
44	TRANSVERSAL AXLE HL-29 101.66	3	1986	new
45	BAROSTAT LUN 6710-05	2	1989	new
46	BAROSTAT LUN 6710-05	5	1989	repairs needed
47	COUPLING PIPE NIPPLE L-29 5000.0001	151	1984	new

48	COUPLING PIPE NIPPLE L-29 5500.0003	77	1984	new
49	COUPLING PIPE HYDRAULIC NIPPLE L-29 5500.0002	10	1984	new
50	BLOCK A FOR RTL-11 STATION	1	1984	repairs needed
51	BLOCK B FOR RTL-11 STATION	1	1984	repairs needed
52	BLOCK C FOR RTL-11 STATION	1	1984	repairs needed
53	LITROMETER ELECTRONIC BLOCK LUN-1643-8	2	1972	repairs needed
54	BLOCK No. 12 275-0014	1	1972	new
55	BLOCK OV FOR RTL-11 STATION	1	1972	repairs needed
56	BLOCK RELAY L-29 83-00-02-P3	1	1972	new
57	BLOCK U FOR RTL-11 STATION	1	1977	repairs needed
58	BLOCK ZM FOR RTL-11 STATION	1	1979	repairs needed
59	RUDDER BLOCKING ZAHL-229-04	1	1979	new
60	START COIL LUN-2245-05	6	1989	repairs needed
61	START COIL LUN-2245-05(03)	4	1989	repairs needed
62	DRIVING DISK BOLT L-29 503.1.007	2	1984	new
63	FUEL PIPE BOLT 0-0146	20	1984	new
64	OIL PIPE BOLT 3147-A-6	10	1984	new
65	FASTENING BOLT L-29 5003.11.11	80	1984	new
66	IGNITING PLUG M 701-N80-3Y-1/25	26	1984	new
67	BELLOWS XL-29 706-14-07	12	1984	new
68	FEEDING PLUG HL-29 712-01-3	193	1984	new
69	PLUG HL-29 701-18-02-01	10	1984	new
70	ADDITIONAL TANK PLUG L-29	9	1984	new
71	PLUG XL-29 712-06	25	1984	new
72	AIR BOTTLE HL-229-03-P1	6	1975	new
73	AIR BOTTLE HL-229-881-03P1A of 1.3 litres	14	1968	new
74	FIRE BOTTLE L-29 8121-8	9	1979	repairs needed
75	OXYGENE BOTTLE MA-4	3	1979	repairs needed
76	BUTTON 204K	33	1984	new
77	CHANNEL COMMAND BUTTON SR-20.14.000	2	1984	new
78	COMMAND BUTTON SR-46.10.10	5	1984	new
79	CHANNELS SWITCH BUTTON SR-12.10.09	30	1984	new
80	MOBILE CAB WITH LOCKS HL-229-104	2	1984	new
81	REARWARD PLEXIGLASS SLIDING CAB L-29 M-105	9	1984	new
82	FORWARD PLEXIGLASS FOLDING CAB L-29 M-104	1	1984	new
83	CABLE 5 QK 644 M82	4	1984	new
84	CABLE 5 QK 644 8106	4	1984	new
85	CABLE 5 QK 644 87	2	1984	new
86	DRIVING CABLE SA-102-03-06	50	1984	new
87	THERMOCOUPLING CABLE set x 4 ea SE 64-00	21	1984	new
88	FRAME XL-29 -712-025	1	1984	new
89	CAB PRESSURIZATION COMPARTMENT 1 HL-229.881.21	2	1984	new
90	TUBE 400*150	36	1997	repairs needed
91	TUBE 600*180	9	2000	repairs needed
92	CONTROL COVER HL-229 103-51P2	2	1984	new
93	CONTROL CAP HL.301.25	2	1984	new
94	CONTROL COVER L-29.111.50.P96	2	1984	new
95	CONTROL COVER L-29.111.50.P6	2	1984	new
96	CONTROL COVER L-29.8301.02P1P	2	1984	new
97	UNDERCARRIAGE RELEASING COVER SE 57-15-00	2	1984	new
98	SHUNT COVER VA-240 SA 45-08-01	2	1984	new
99	STARTER PROTECTION HOUSING 05-113P	1	1984	new
100	UNIVERSAL JOINT AI 229-503-10-36	2	1984	new
101	NOZZLE COWLING L-229-6037	3	1984	new
102	REACTIVE NOZZLE COWLING AI 229.60.37	5	1984	new
103	FRONT COWLING WITH GASKET L-29 301 29	3	1984	new

104	FRONT COWLING HL 229.301.29 P1G	10	1984	new
105	CAB COWLING HL 229-101-01	2	1984	new
106	RADIOCOMPASS COVER COWLING L-29 111.5008	9	1984	new
107	RH BACK WING BRACKET COWLING	113	1984	new
108	LH BACK WING BRACKET COWLING 2920321 P2	113	1984	new
109	RH PLAN TOP BRACKET COWLING L-29 204-21 P1D	105	1984	new
110	LH PLAN TOP BRACKET COWLING L-29 203 HL2920321P	4	1984	new
111	LH TOP BRACKET COWLING L-29 20.3	109	1984	new
112	LH-RH COWLING AL-29 203/204	2	1984	new
113	LH-RH COWLING AL-29 203/204 21P1	2	1984	new
114	FRONT COWLING AL-229.503.01	9	1984	new
115	RH MID COWLING HL-229.301.29.P3	2	1984	new
116	BACK COWLING AL-229.301.28.P2F	2	1984	new
117	STATION COWLING 020 AL-229.101.12.P3	9	1984	new
118	LH PLAN TOP COWLING AL-229.203.21	4	1984	new
119	BELT C-5101-2600	2	1984	new
120	TANK FIXING BELT L-229.706.26	2	1984	new
121	TANK FIXING BELT L-29.706.21	2	1984	new
122	ANTENNA PROTECTION FAIRING AL-229.101.1220	21	1984	new
123	REAR FUSELAGE FAIRING 229-6037	5	1984	new
124	COLLECTOR M 701-04-101-6	50	1984	new
125	COLLAR CSN 02.2752	11	1984	new
126	FRONT LEG NIGHT FLIGHT LAMP COLLAR SA 11 20 09	2	1984	new
127	COLLAR M 701-03-540	50	1984	new
128	COLLAR M 701-06-309	90	1984	new
129	COLLAR M 7019-06-815	5	1984	new
130	COLLAR M 701-05-769	10	1984	new
131	MAGNETIC COMPASS GIK-1	7	1984	new
132	MAGNETIC COMPASS LUN 1221-8	2	1984	new
133	FLEXIBLE PIPE 116*254CSN13 7822	12	1984	repairs needed
134	FLEXIBLE PIPE 13*420CSN13 7822	3	1984	repairs needed
135	FLEXIBLE PIPE 13*485CSN13 7821	4	1984	repairs needed
136	FLEXIBLE PIPE 2*330CSN13 7822 3A	4	1984	repairs needed
137	FLEXIBLE PIPE 4*290CSN13 7822 3A	1	1984	repairs needed
138	FLEXIBLE PIPE 6*330CSN13 7823 2A	10	1984	repairs needed
139	FLEXIBLE PIPE 6*420CSN13 7822 3	16	1984	repairs needed
140	FLEXIBLE PIPE 6*460CSN13 7821 3A	5	1984	repairs needed
141	FLEXIBLE PIPE 6*490CSN13 7822 1A	4	1984	repairs needed
142	FLEXIBLE PIPE 6*492CSN13 7822	14	1984	repairs needed
143	FLEXIBLE PIPE 6*545CSN13 7821 3A	20	1984	repairs needed
144	FLEXIBLE PIPE 8*285CSN13 7822 3A	6	1984	repairs needed
145	FLEXIBLE PIPE 8*295CSN13 7822 3A	5	1984	repairs needed
146	FLEXIBLE PIPE 8*310CSN13 7822 3A	4	1984	repairs needed
147	FLEXIBLE PIPE 8*360CSN13 7822 3A	1	1984	repairs needed
148	FLEXIBLE PIPE 8*375CSN13 7822 3A	2	1984	repairs needed
149	ABSORPTION FLEXIBLE PIPE FOR PUMP 623.13445	8	1984	repairs needed
150	FLEXIBLE PIPE AL 229 70713P20	23	1984	repairs needed
151	FLEXIBLE PIPE AL 229 707 13P20A	2	1984	repairs needed
152	FLEXIBLE PIPE AL 229 709 7101P1	2	1984	repairs needed
153	FLEXIBLE PIPE AL 229 711-10-09A	4	1984	repairs needed
154	FLEXIBLE PIPE AL 229-862-01P132	2	1984	repairs needed
155	FLEXIBLE PIPE AL 229-881-15P9-30VEA	2	1984	repairs needed
156	FLEXIBLE PIPE AL 29-880-174-69-41	5	1984	repairs needed
157	FLEXIBLE PIPE AL 29-880-174-69-42	3	1984	repairs needed
158	DISCHARGING FLEXIBLE PIPE FOR PUMP 623.10*335 L-29	15	1984	repairs needed
159	OXYGEN PIPE SO 22-00-00 set x 11 ea.	4	1984	new

160	CONTACTOR LUN 2288	2	1984	repairs needed
161	RH LEG FOLDING BRACE STRUT L 229 50211A	14	1973	new
162	LH LEG FOLDING BRACE STRUT L 229 50111A	13	1973	new
163	ANTENNA PROTECTION BODY AL 229.101 02	2	1979	new
164	ANTENNA PROTECTION BODY AL 229.101 03	4	1979	new
165	VALVE BODY 8 LUN 7373	14	1979	new
166	VALVE BODY OKN 30-1	3	1979	new
167	QUARTZ A AND B FOR RSIU	1	1979	new
168	QUARTZ KI-16 MHZ	2	1979	new
169	QUARTZ FOR RTL-11 STATION	6	1979	new
170	COUPLING JD-17-01-05-M	5	1979	new
171	CONNECTION BOX SK-18	1	1979	new
172	CONNECTION BOX SK-18	3	1979	repairs needed
173	STARTER LUN 2259	10	1979	new
174	STARTER LUN 2259	4	1979	repairs needed
175	STATIC ELECTRICITY DISCHARGER FOR. L-29	26	1982	new
176	RUDDER L-29-312	5	1982	new
177	FRICTION DISK HL-229 701.01.04	54	1982	new
178	FRICTION DISK HL-229 701.01.09	56	1982	new
179	DEVICE (SEPARATOR FILTER) L-29 8006.02	8	1982	new
180	CONTROL HANDLE FASTENING DEVICE ZAHL 229	1	1982	new
181	CONTACTORS INERTIA CHECKING DEVICE ARZ 7000	1	1982	new
182	NEUTRAL POSITION PEDALS FIXING DEVICE	1	1982	new
183	FLAPS OPERATING DEVICE HL-29 411.01	2	1982	new
184	FLAPS OPERATING DEVICE HL-29 411.02	2	1982	new
185	REVERSING DISTRIBUTOR GA-57	9	1982	new
186	REVERSING DISTRIBUTOR GA-57	3	1982	repairs needed
187	CORK N 14*1,5CSNB 79642	4	1982	new
188	THERMOCOUPLING SOCKET SD-11.21	6	1982	new
189	CHOKE LN 0652	5	1982	new
190	TAILPLANE SWITCH ELECTROMECHANISM LUN 2510-01	2	1982	new
191	TAILPLANE SWITCH ELECTROMECHANISM LUN 2510-0	5	1982	repairs needed
192	ELECTROMOTOR 850-140 EIRC	2	1982	new
193	ELECTROMOTOR 850-S-140	1	1982	new
194	ELECTROMOTOR DPM-30 NI-01	5	1982	new
195	ELECTROMOTOR EG-2	2	1982	new
196	ELECTROMOTOR ER 40N7	1	1982	new
197	PUMP ASSEMBLING UNIT AL 29 707 Z.1	2	1982	new
198	VALVE UNIT AL 229 707.32	2	1982	new
199	RH AILERON HL-29 226 (echipat)	3	1982	new
200	RH AILERON HL-29 226 neechipat	3	1982	new
201	LH AILERON HL-29 225 echipat	4	1982	new
202	LH AILERON HL-29 225 neechipat	3	1982	new
203	BEACON FS-155	1	1982	repairs needed
204	BEACON LFSV-45	1	1982	repairs needed
205	RUN BEACON FR-100	12	1982	new
206	FILTER 271-700 pt. VM 0605-820	8	1982	new
207	FELT AIR FILTER 721-706 pentru 721-70 OA	77	1982	new
208	FILTER F-14A	1	1982	repairs needed
209	FILTER F-14A	28	1982	new
210	FILTER FG-11/1S	27	1982	new
211	FILTER FG-11/1S	4	1982	repairs needed
212	FINE FILTER TT-5500-1700E	2	1982	new
213	FILTER SF 3000R	10	1982	new
214	FILTER SF 3000R	5	1982	repairs needed
215	FEEDER FLANGE HL-29 712.03.4	20	1982	new

216	RH FLAPS HL-29-208	11	1982	new
217	LH FLAPS HL-29-207	8	1982	new
218	LH FLAPS HL-29-209	6	1982	new
219	PHOTOMACHINE GUN FKP-2-1	1	1982	new
220	PHOTOMACHINE GUN FKP-2-2	1	1982	repairs needed
221	AERODYNAMIC BRAKE HL-2299 113.48	12	1982	new
222	ADJUSTUNG CRADLE HL-229 401.130.1	7	1982	new
223	NOSE UNDERCARRIAGE LEG CRADLE L-29 503.1.P7	6	1982	new
224	FRONT WHEEL (NOSE GEAR) CRADLE L-29 603.10.P6	2	1982	new
225	GASKET 155N-607-39,4	40	1982	new
226	GASKET 26A-2-14-20	60	1982	new
227	GASKET 526.100.76	40	1982	new
228	GASKET 74.7205.112	60	1982	new
229	GASKET Cu 6110-265	160	1982	new
230	GASKET HL-29 712-18-07	160	1982	new
231	GASKET HL-29 712-07	30	1982	new
232	GASKET HL-29 712-18-06A	60	1982	new
233	GASKET HL-29 715-010	9	1982	new
234	GASKET HL-29 715-05	5	1982	new
235	GASKET M 701	28	1982	new
236	GASKET M 701-02-338	75	1982	new
237	GASKET M 701-02-436	600	1982	new
238	GASKET M 701-02-477	434	1982	new
239	GASKET M 701-04-477	500	1982	new
240	GASKET M 701-06-206	154	1982	new
241	GASKET M 701-06-840	30	1982	new
242	GASKET SE 52-01-30	270	1982	new
243	GASKET VM 7601-62	28	1982	new
244	GASKET XL-29 712-012	18	1982	new
245	GASKET XL-29 712-014	57	1982	new
246	GASKET XL-29 712-043	13	1982	new
247	GLASS plexiglass L 13.105.02.07	5	1982	new
248	CABIN WINDSCREEN plexiglass HL-229.101	2	1982	new
249	RIM 600*180 K 600-1200	2	1982	new
250	GENERATOR 28V-3000W LUN 2117-01	8	1982	new
251	GENERATOR 28V-3000W LUN 2117-01	2	1982	repairs needed
252	GENERATOR GSR 3000M	6	1982	new
253	GYROAGGREGATE G-3M pt. GIK 1	19	1982	new
254	ADDITIONAL TANK BEAM AL-29-711	2	1982	new
255	HYDROACCUMULATOR VM 5505-130	5	1979	repairs needed
256	HYDROACCUMULATOR VM 5505-130-3	4	1979	new
257	PANEL HOOD SA-HA-0110	10	1979	new
258	HEATER 25-1020	3	1979	new
259	TURN AND SLIDE INDICATOR LUN 1213-1-2	5	1979	repairs needed
260	TURN AND SLIDE INDICATOR LUN 1213-1-2	4	1979	new
261	INDICATOR LUN-1213-2 viraj și glisadă	1	1979	new
262	TRIPLE ELECTRIC INDICATOR LUN 1525	12	1979	new
263	FUEL LITROMETER INDICATOR LUN 1627	4	1979	repairs needed
264	FUEL LITROMETER INDICATOR LUN 1627	18	1979	new
265	MACH INDICATOR MS 1(8)	12	1979	new
266	MECHANICAL INDICATOR HL-29 501-05	1	1979	new
267	LANDING-GEAR POSITION INDICATOR LUN 1694	12	1979	new
268	RADIOCOMPASS INDICATOR 7 SUS	1	1979	new
269	TACHOMETER INDICATOR ITE 1	3	1979	new
270	THERMOMETER INDICATOR TVG 1	4	1979	repairs needed
271	INDICATOR UGR 1	8	1979	new

272	INDICATOR UGR 1	4	1979	repairs needed
273	SPEED INDICATOR KUS 1200	4	1979	repairs needed
274	RING 10*14 CSN 02.9310.3	130	1979	new
275	RING 12*18CSN 02.9310.3	235	1979	new
276	RING 155N-607-11,6-3,25	60	1979	new
277	RING 155N-607-15,6-3,25	60	1979	new
278	RING 155N-607-17,6	40	1979	new
279	RING 155N-607-23,6-3,25	32	1979	new
280	RING 155N-607-29,6-3,25	20	1979	new
281	RING 155N-607-35,4	25	1979	new
282	RING 155N-607-33,6-1	20	1979	new
283	RING 16*22CSN 02.9310.3	40	1979	new
284	RING 20*24CSN 02.9310.3	20	1979	new
285	SEALING RING 10*14CSN 02-9310-2	30	1979	new
286	SEALING RING 12*16CSN 02-9310-3	49	1979	new
287	SEALING RING 14*18CSN 02-9280-2	23	1979	new
288	SEALING RING 16*22CSN 02-9310-3	3	1979	new
289	SEALING RING 22*29CSN 02-9310-3	130	1979	new
290	SEALING RING 28*36KSND 29-28-02	11	1979	new
291	SEALING RING M 701-02-422	341	1979	new
292	SEALING RING M 701-05-418	331	1979	new
293	SEALING RING M 701-05-455	384	1979	new
294	SEALING RING M 701-902-401	240	1979	new
295	RING M 701-02-431	100	1979	new
296	RING M 701-05-573	20	1979	new
297	RING M 701-06-688	20	1979	new
298	RING M 701-25-137	51	1979	new
299	RING M 701-25-357	6	1979	new
300	RING M 701-870	51	1979	new
301	OXYGEN INHALER KP-18	1	1979	new
302	INJECTOR 06-1156-B	154	1979	new
303	INJECTOR 06-1156-B	23	1979	repairs needed
304	INJECTOR 06-1156-C	37	1979	new
305	INJECTOR 06-1156-D	3	1979	new
306	INJECTOR 06-1156-T	3	1979	new
307	INJECTOR 06-1156-A	100	1979	new
308	MISSILE INSTALLATION AV 29 FOR RS 57 MISSILE	1	1984	new
309	MISSILE INSTALLATION AV 29 FOR RS 57 MISSILE	2	1984	repairs needed
310	SWITCH 2PP 45	37	1984	new
311	SWITCH 2VG 15	4	1984	new
312	SWITCH 2VG 15 K 2S	7	1984	new
313	AUTOMATIC SWITCH AZR-2	10	1984	new
314	HEATING KNOB SWITCH PVD-LUN 3215-8	4	1984	repairs needed
315	CORRECTION SWITCH VK 53PB	9	1984	repairs needed
316	SWITCH LUN 3157-7	57	1984	new
317	SWITCH LUN 3211-8	200	1984	new
318	SWITCH PP 45	16	1984	new
319	Înterupător PZPN 20	11	1984	new
320	LANDING-GEAR SWITCH LUN 3251-02	2	1984	repairs needed
321	NOSE UNDERCARRIAGE LEG AL 229-513/10-503-10	28	1974	new
322	NOSE UNDERCARRIAGE LEG AL 229-513/10-503-10	8	1974	repairs needed
323	MAIN LEG AL 229-501-10	50	1974	new
324	RH MAIN LEG AL 229-502-10	40	1974	new
325	RH MAIN LEG AL 229-502-10	7	1974	repairs needed
326	FRONT WHEEL RIM 400*150 44-1	2	1974	new
327	BRAKE MAIN WHEEL RIM K 600 12DU-UG	2	1974	new

328	MAIN WHEEL RIM L-29 K 600 1BP 600*180	2	1974	new
329	FRONT WHEEL RIM 400*150 44-1	1	1974	repairs needed
330	BRAKE MAIN WHEEL RIM K 600 12DU-UG	1	1974	repairs needed
331	MAIN WHEEL RIM L-29 K 600 1BP 600*180	1	1974	repairs needed
332	CABIN LOCK HL-229 101-71P11	2	1974	new
333	REAR CABIN LOCK HL-229 105.06	3	1974	new
334	MAIN LEG RH LOCK HL-229 502.07	6	1974	new
335	MAIN LEG RH LOCK HL-229 502.07	1	1974	repairs needed
336	HYDRAULIC TWO-SIDED LOCK LUN 7531.01.2(02.2)	37	1974	new
337	HYDRAULIC LOCK LUN 7182-1	8	1974	new
338	HYDRAULIC LOCK LUN 7182-2	4	1974	new
339	HYDRAULIC LOCK LUN 7531.02.3	36	1974	new
340	HYDRAULIC LOCK LUN 7531.02.3	1	1974	repairs needed
341	UNIVERSAL HYDRAULIC LOCK 6LUN 7538	37	1974	new
342	LEG LOCK HL-229-502-07	3	1974	new
343	RH MAIN LEG LOCK AL-229	5	1974	new
344	MAIN LEG LOCK HL-229.501.07	18	1974	new
345	LH MAIN LEG LOCK AL-229.501.07	2	1974	new
346	NOSE LEG MECHANICAL LOCK L-29-503-11	4	1974	repairs needed
347	FRONT CAB RH LOCK HL-229.101.68	14	1974	new
348	FRONT CAB RH LOCK HL-229.101.68	1	1974	repairs needed
349	BACK CAB RH LOCK HL-229.105.04	11	1974	new
350	FRONT CAB LH LOCK HL-229.101.67	10	1974	new
351	BACK CAB LH LOCK HL-229.105.03	11	1974	new
352	RH PANEL LOCK HL-229.502.08	27	1974	new
353	RH PANEL LOCK HL-229.502.08	1	1974	repairs needed
354	CAB LAMP ARUFOS 45M	37	1974	new
355	PROTECTION NECK SE 24-04-00	55	1974	new
356	HANDLE WITH PLUG L-29-8401-03	10	1974	new
357	FOLDING CANOPY HANDLE HL-229-101-74	11	1974	new
358	AIR MANOMETER MA-160	7	1974	new
359	AIR MANOMETER MA-250M	25	1974	new
360	AIR MANOMETER MV-100	4	1974	new
361	AIR MANOMETER MV-100M	19	1974	new
362	AIR MANOMETER MV-60	2	1974	new
363	AIR MANOMETER MV-60M	6	1974	new
364	AIR MANOMETER MV-80	15	1974	new
365	HYDRAULIC MANOMETER MG-160M	22	1974	new
366	MANOMETER MA-250	8	1974	new
367	MANOMETER MA-250	2	1974	repairs needed
368	MANOMETER MA-250KM	1	1974	new
369	MANOMETER MA-4	1	1974	new
370	MANOMETER MA-60	2	1974	new
371	SLEEVE HL-29-706-14-07	45	1974	new
372	SLEEVE SD 02-05-134	9	1974	new
373	TRAP DOOR ACTUATOR AL-229-503-03	1	1974	new
374	LEG PANEL CONTROL DEVICE AL-229.503.03	8	1974	new
375	FLAPS AND SLOTS CONTROL DEVICE HL-229-411-01-P7	2	1974	new
376	FLAPS AND SLOTS CONTROL DEVICE HL-229-411-02-P7	3	1974	new
377	ADJUSTMENT DEVICE KM-8	1	1974	repairs needed
378	CANOPY AVERAGE JETTISON UNIT HL-229-105-11	2	1974	new
379	AVERAGES JETTISON UNIT XL-229.101.75	4	1974	new
380	CANOPY JETTISON DEVICE HL-229.101.76	15	1974	new
381	PYROTECHNICAL DEVICE L-29-841-08	2	1974	new
382	TERMINAL MOUNT L-29-524	1	1974	new
383	ANTENNA PROTECTION RIB 1A AL-229-101-03	3	1974	new

384	CONTROL PANEL FFFS-28MT	1	1974	new
385	START PANEL LUN 2273-02	16	1974	repairs needed
386	SHOE SV 02-05-11	9	1974	new
387	TRIMMING LEVER HL-229-403-04P1	3	1974	new
388	HANDLE CONTROL LEVER HL-229-402-1P1	4	1974	new
389	SWING BAR CONTROL LEVER HL-229-403-04P2	3	1974	new
390	ACTION LEVER HL-29-405-01P1	5	1974	new
391	CONTROL LEVER HL-29-409-04-P2	1	1974	new
392	AILERON LEVER HL-29-402-01P2	3	1974	new
393	AILERON LEVER HL-29-402-01P3	4	1974	new
394	SWIVELLING LEVER HL-229-101-76-P4	20	1974	new
395	REARWARD SPRING LOCKING LEVER HL	1	1974	new
396	FUSELAGE BACKSIDE WITH ASSEMBLED FIN L-29-113	2	1974	new
397	WHEEL RH SIDEI K-600-12-02	3	1974	new
398	AIR COUPLING FRONT PART L-29-201	2	1974	new
399	FUSELAGE FRONT PART AL-229-101-21	5	1974	new
400	AIR INTAKE FRONT PART L-29-201-49	1	1974	new
401	AIR INTAKE FRONT PART L-29-201-50	1	1974	new
402	AIR COUPLING REAR SIDE L-29-201-50	2	1974	new
403	WHEEL LH PART K-600-12-01	3	1974	new
404	FUSELAGE MID SIDE L-29 M.112	1	1974	new
405	INTERMEDIARY TIP SO 03-01-24A	4	1974	new
406	CONTROL PEDAL H-29-401-01-P7	3	1974	new
407	PISTON GA-57-00-3A	77	1974	new
408	NUT (STOPPER) WITH CHAIN SD 07-01-25	8	1974	new
409	THERMOCOUPLING CONNECTING PLATE K-80	1	1974	new
410	FERRODO BRAKE PLATE BN 600-0124	217	1974	new
411	BRAKE PLATE L-29-514-09-05	56	1974	new
412	METALLIC PLATE WITH SCALE 0-20 IE 671-144	4	1974	new
413	BRAKE PLATE BG 600-01-24	1156	1974	new
414	BRAKE PLATE BG 600-01-22	1756	1974	new
415	BRAKE PLATE BG 600-01-23	1677	1974	new
416	RH ASSEMBLED PLAN HL-29-M214	2	1974	new
417	LH ASSEMBLED PLAN HL-29-M213	3	1974	new
418	FUEL PUMP LUN 6201-06	4	1974	repairs needed
419	HYDRAULIC PUMP 29-623	30	1974	new
420	HYDRAULIC PUMP 29-623	3	1974	repairs needed
421	PUMP FOR 1V	6	1974	repairs needed
422	SOCKET 47K	9	1974	new
423	AIR INTAKE HL-229-712-011	8	1974	new
424	SUPPLY SOCKET SR 4-11-VU	4	1974	new
425	4 CONTACTS SOCKET SD 35-01-00	3	1974	new
426	TEMPERATURE COUPLING SOCKET TUE 48	21	1974	new
427	SINGLE POLE SOCKET SR 25-23-00	1	1974	new
428	PROTECTION UNIT SA 111-08-10	40	1974	new
429	PROTECTION UNIT SA 111-08-12	20	1974	new
430	CONNECTING PIECE 2740-A12	10	1982	new
431	CONNECTING PIECE 2776-A6	10	1982	new
432	CONNECTING PIECE AL-29-204-05P8	100	1982	new
433	STRAIGHT CONNECTOR 2712-A6	18	1982	new
434	THREADED CONNECTOR LN 5021	20	1982	new
435	THREADED CONNECTOR M 701-06-769	15	1982	new
436	TILT CONNECTOR M 701-06-347	90	1982	new
437	TELESCOPIC CONNECTOR (CONNECTOR ROD) HL	49	1982	new
438	AIR RADIATOR S-186	7	1982	new
439	CONTROL HANDLE PROTRACTOR ZAHL-229	1	1982	new

440	RECEIVER P-158	1	1982	repairs needed
441	PRESSURE RECEIVER LUN 1563	1	1982	new
442	PRESSURE RECEIVER P-100	3	1982	repairs needed
443	PRESSURE RECEIVER P-10M	1	1982	new
444	PRESSURE RECEIVER P-100	18	1982	new
445	PRESSURE RECEIVER P-18	11	1982	new
446	PRESSURE RECEIVER P-3B	15	1982	new
447	OIL PRESSURE RECEIVER LUN 1562	29	1982	new
448	RADIOMARKING RECEIVER MPR-56M	4	1982	new
449	PITOT'S TUBE RECEIVER PVD-6M	8	1982	new
450	OXYGEN REDUCER KP-14A	13	1982	new
451	OXYGEN REDUCER KR-14	1	1982	new
452	OXYGEN REDUCER KR-14A	2	1982	repairs needed
453	REDUCER RV 07-VIA	3	1982	new
454	REDUCER RV 07-VIA	5	1982	repairs needed
455	REDUCER RV 50MV-29	7	1982	repairs needed
456	REDUCER RV 50MV-29(RV 50MV-8)	6	1982	new
457	REDUCER RV 50MV-29(RV 50MV-8)	1	1982	repairs needed
458	REDUCER RV-3V-29	27	1982	new
459	REDUCER RV-3V-29	2	1982	repairs needed
460	TERMINAL STRIP 73K	3	1982	new
461	VOLTAGE REGULATOR R 27	1	1982	repairs needed
462	PRESSURE REGULATOR RD 21A	1	1982	repairs needed
463	PRESSURE REGULATOR RD 21A-29	10	1982	new
464	PRESSURE REGULATOR RD 21A(RD 21A-29)	23	1982	new
465	REGULATOR R 25AM	7	1982	new
466	TEMPERATURE REGULATOR TRTVK-45M	6	1982	repairs needed
467	VOLTAGE REGULATOR R 27L	4	1982	new
468	VOLTAGE REGULATOR R 27VT	1	1982	new
469	VOLTAGE REGULATOR R 27	11	1982	repairs needed
470	DIFFERENTIAL RELAY LUN 2600.01	14	1982	new
471	MINIMUM DIFFERENTIAL RELAY DMR-200D	1	1982	repairs needed
472	MINIMUM DIFFERENTIAL RELAY DMR-400DSP	1	1982	repairs needed
473	RELAY DMR-400A	1	1982	new
474	RELAY DMR-400AM	1	1982	new
475	RELAY DMR-400D	2	1982	new
476	RELAY DMR-400D	2	1982	repairs needed
477	RELAY DMR-400DSI	1	1982	repairs needed
478	RELAY DMR-400DSP	2	1982	repairs needed
479	RELAY KRS-1	2	1982	new
480	RELAY RP-3	1	1982	new
481	RELAY RP-6	1	1982	new
482	RELAY RP-6	2	1982	repairs needed
483	RELAY RT-40	19	1982	new
484	RELAY TDE-210	9	1982	new
485	RELAY TKE-21PDT	3	1982	repairs needed
486	RELAY TKE-52PDT	7	1982	new
487	RELAY TKE-52PDT	1	1982	repairs needed
488	RELAY TKE-54PDI	4	1982	new
489	RELAY TKE-56PDT C ONTROL	4	1982	new
490	CAB LAMP RHEOSTAT 26V-70ohmi	1	1984	new
491	RHEOSTAT RL-70	6	1984	new
492	RHEOSTAT RUFO	10	1984	new
493	FUEL DISTRIBUTING FRAME LUN 5200-05	5	1984	repairs needed
494	SPRING HL-29-826-01-55	75	1984	new
495	SPRING HL-29-826-01-55(826-01-56)	94	1984	new

496	VENT TANK 06-1221	7	1984	new
497	HYDRAULIC TANK L-29-8604-05	20	1984	new
498	SPARE TANK HL-29-712	31	1984	new
499	DECODING RULER 5 QL-101-00	2	1984	new
500	CAB SUPPLY TAP 29VM 7601-10	43	1984	new
501	BRAKE DAMAGES TAP ST 5500-200	5	1984	repairs needed
502	PITOT'S TUBE PRESSURE SWITCH TAP 29.623.700M	4	1984	repairs needed
503	PITOT'S TUBE PRESSURE SWITCH TAP 29.623.700M	20	1984	new
504	GAUGING TAP LUN 7572-05	2	1984	new
505	GAUGING TAP LUN 7572-05	2	1984	repairs needed
506	ELECTROHYDRAULIC TAP LUN 7420-04DVP	31	1984	new
507	ELECTROHYDRAULIC TAP LUN 7420-04DVP	3	1984	repairs needed
508	ELECTROHYDRAULIC TAP LUN 7420-05-06	59	1984	new
509	PRESSURIZED CABIN TAP II VM 0602-100	30	1984	new
510	PRESSURIZED CABIN TAP II VM 0602-100	2	1984	repairs needed
511	HYDRAULIC TAP LUN 7420-01	5	1984	new
512	OXYGEN TAP KV-2	22	1984	new
513	OXYGEN TAP KV-2MS	16	1984	new
514	OXYGEN TAP KV-2MS	9	1984	repairs needed
515	OXYGEN TAP KV-2MS	30	1984	new
516	AIR TAP LUN 7355	34	1984	new
517	DAMAGES TAP - HIGH PRESSURE LUN 7373	43	1984	new
518	CAB TAP I ST 0603-200	30	1984	new
519	CAB TAP I ST 0603-200	3	1984	repairs needed
520	PROOF TAP ST 5500-020-02-8	1	1984	repairs needed
521	DISK 16*22 CSN 02-9310-2	23	1979	new
522	DISK M 701-02-431	923	1979	new
523	ADJUSTING DISK M 701-26-112	58	1979	new
524	PROOF DISK 90-04-01-11	10	1979	new
525	BEARING 6002-CSN 024-653	3	1979	new
526	BEARING CSN 02-4720-32213	6	1979	new
527	BEARING CSN 02-4721-32213	15	1979	new
528	BEARING GOST 900-706	18	1979	new
529	BEARING NUM 4032-308 NU 308	1	1979	new
530	SEGMENT M701-02-401	100	1979	new
531	SELECTOR 852-160-01	2	1979	new
532	SELECTOR 852-160-01	2	1979	new
533	OIL-SEAL RING 59511	16	1979	new
534	FRONT LEG OIL-SEAL RING 50*68 PM 60-01	8	1979	new
535	PUMP OIL-SEAL RING 623-275-007	150	1979	new
536	MAIN UNDERCARRIAGE HALFCRADLE AL 238501-10P8	4	1979	new
537	CAB DANGEROUS PRESSURE SIGNAL UNIT LUN 1467-01-18	17	1979	new
538	PRESSURE SIGNAL UNIT SD-3	2	1979	repairs needed
539	PRESSURE SIGNAL UNIT SD-3	9	1979	new
540	WATER SEPARATOR (SEPARATOR GLASS) VH2-7702620	16	1979	new
541	DRAWER HL-29712	24	1979	new
542	ALARM LUN 2683	2	1979	repairs needed
543	RADIO STATION R-832 M-117	1	1984	new
544	RADIO STATION RTL-11	1	1984	new
545	CONNECTING PIPE 155 N 816-14-24-25	10	1979	new
546	AIR FEEDING CONNECTING PIPE L-29-3109-8	4	1979	new
547	TRANSIT CONNECTING PIPE LUN 7730-01	107	1979	new
548	FUEL VENT CONNECTING PIPE LUN 7346-01	5	1979	new
549	CONNECTING PIPE M 701 06-427	23	1979	new
550	CONNECTING PIPE M 701 25-245	10	1979	new
551	CONNECTING PIPE M 701 25-356	90	1979	new

552	CONNECTING PIPE M 701 05-603	15	1979	new
553	CONNECTING PIPE MGA 57-03 A	9	1979	new
554	CAB TIGHTNESS CHECKING CONNECTING PIPE	4	1979	new
555	VALVE 1890-A1T	87	1982	new
556	VALVE 25-538	322	1982	new
557	VALVE 3509-550	2	1982	new
558	INTAKE VALVE K-14A	3	1982	new
559	DAMAGES VALVE 688.600	3	1982	repairs needed
560	DAMAGES VALVE 668-600E(A/V)	1	1982	new
561	DAMAGES VALVE 668-600V	5	1982	new
562	ADJUSTING VALVE 634-700M/E	52	1982	new
563	ADJUSTING VALVE 634-700M/E	21	1982	repairs needed
564	TIGHTENING TIP VALVE SO 03-020M	7	1982	new
565	FLOAT VALVE AC 29706	7	1982	new
566	HYDRAULIC SYSTEM INTAKE VALVE 668-500E(668-600E)	37	1982	new
567	DAMAGES VALVE 668-600A	126	1982	new
568	COUPLING VALVE SCM 01-12	3	1982	new
569	REDUCTION VALVE LUN 7530-01(7350-01)	14	1982	new
570	REDUCTION VALVE LUN 7330-01-3	32	1982	new
571	RETAINING VALVE LUN 7532-011	1	1982	new
572	SAFETY VALVE LUN 7540	74	1982	new
573	SAFETY VALVE PK-29	19	1982	new
574	GRAVITATIONAL VALVE LUN 7582	86	1982	new
575	VALVE HL-29-712-09	109	1982	new
576	AERODYNAMIC BRAKE EXIT VALVE LUN 773001-773001	5	1982	new
577	VALVE LUN 7534-01	44	1982	new
578	VALVE LUN 7534-01 joc a 4 ea.	60	1982	new
579	VALVE OKM-30A	34	1982	new
580	VALVE OKM-30A	1	1982	repairs needed
581	1 WAY OXYGEN VALVE 11162	4	1982	new
582	VALVE PK-29A	10	1982	new
583	DISTRIBUTING VALVE E-31 LUN 7600-1040	18	1982	new
584	REVERSING VALVE 10 LUN 7581	71	1982	new
585	REVERSING VALVE 16 LUN 7581	32	1982	new
586	1 WAY VALVE 10 LUN 7581-01-8	25	1982	new
587	1 WAY VALVE 668-400E(663-400E)	121	1982	new
588	1 WAY VALVE 669-001	81	1982	new
589	1 WAY VALVE 669-001	1	1982	repairs needed
590	1 WAY VALVE 8 LUN 7532-01	9	1982	new
591	1 WAY VALVE 8/3 LUN 7534-01	29	1982	new
592	1 WAY VALVE 998-A4/V/A	82	1982	new
593	1 WAY VALVE 998-A4/V/A	14	1982	repairs needed
594	1 WAY VALVE LUN 7341-01	43	1982	new
595	1 WAY VALVE LUN 7341-01	1	1982	repairs needed
596	1 WAY VALVE SR-41-3100	6	1982	new
597	1 WAY VALVE 6 LUN 7538-01	32	1982	new
598	CAB PROOFING SAFETY VALVE 3,5 Kgf -VM2-0606-VM-2062-E50	23	1982	new
599	SAFETY VALVE 1,5 Kgf/ATM-634-300E	141	1982	new
600	SAFETY VALVE 3,5 Kgf/ATM-634-200	43	1982	new
601	SAFETY VALVE ESI-7600-1040	2	1982	new
602	BEACON HOLDER SD 730200A	54	1984	new
603	LAMP REST SE 340300	15	1984	new
604	ENGINE HOLDER HL-229-601	2	1984	new
605	FLAPS ROLLERS FASTENING SCREW	16	1984	new
606	SCREW M 701-05	6	1984	new
607	DECKING SCREW tip 2	3	1984	new

608	TACHOMETER FITTED WITH 2 TRANSMITTERS DTE-1 ITE-1K	1	1984	new
609	TACHOMETER FITTED WITH 2 TRANSMITTERS DTE-1 ITE-2	1	1984	new
610	THERMOALARM AD 155 NMA 3K	17	1984	new
611	THERMORESISTOR MMT 12 300 ohm	3	1984	new
612	THERMORESISTOR MMT 4A 1,5 ohm	1	1984	new
613	THERMORESISTOR MMT 4A 7,5 ohm	3	1984	new
614	CONTROL ROD 29405-13	6	1984	new
615	CONTROL ROD 29405-14	3	1984	new
616	CATCH ROD L-29 712-06	31	1984	new
617	CONTROL ROD HL 29-450-12	10	1984	new
618	CONTROL ROD HL 29-405-11	10	1984	new
619	LOCKS CONNECTING ROD HL 229 101-71	4	1984	new
620	RH ROD 112-229-1017P5	15	1984	new
621	ROD HL 229-101-76-5	20	1984	new
622	ROD HL 29-105-11P8	12	1984	new
623	ROD NL 229-403-13	7	1984	new
624	LH ROD 112-229-101-31 P4	18	1984	new
625	DOOR ROD AL 229-503-02	2	1984	new
626	TRANSMITTER DI-1	1	1979	repairs needed
627	TRANSMITTER DI-1A	1	1979	repairs needed
628	TRANSMITTER ID pentru GIK-1	2	1979	repairs needed
629	RH LOWER DOOR AL 229-502-01	4	1979	new
630	RH-LH MAIN LEG LOWER DOOR HL 229-501-01 502-01-P	1	1979	new
631	LH MAIN LEG LOWER DOOR HL 229-501-03 502-03	1	1979	new
632	LH LOWER DOOR HL 229-501-011	2	1979	new
633	LH LOWER DOOR L-29 501-03	1	1979	new
634	RH LOWER DOOR HL-229-502-03	9	1979	new
635	RH LEG DOOR HL 229-502-02BV	17	1979	new
636	LH LEG DOOR HL 229-501-02 sfinga	15	1979	new
637	RH WHEEL DOOR HL 229-502-01	19	1979	new
638	LH WHEEL DOOR HL 229-501-01	19	1979	new
639	RH UPPER DOOR HL 229-502-02	1	1979	new
640	LH LUPPER DOOR HL 229-501-02	3	1979	new
641	BALANCE TAB L 229-804-13	7	1984	new
642	SPARE PARTS KIT FOR SRO-2	1	1984	new
643	SPARE PARTS KIT FOR RTL-11 STATION	2	1984	new
644	FIRE TUBE 02-1070	52	1984	new
645	FIRE TUBE 02-1071	32	1984	new
646	PITOT'S TUBE L 29 LH PLAN 8007-0111	1	1984	new
647	PITOT'S TUBE PVD-5	5	1984	repairs needed
648	EXTENTION TUBE 04-1036	3	1984	new
649	TURBOCOOLER 477D	1	1984	repairs needed
650	WING TIPS AL 29-203-21	24	1984	new
651	WING TIPS AL 29-204-01	23	1984	new
652	VENTIL 654-300-A	2	1984	new
653	UNDERCARRIAGE UNLOCKING JACK LUN 7182-2	8	1984	new
654	UNDERCARRIAGE UNLOCKING JACK LUN 7182-2	3	1984	repairs needed
655	FLAPS ACTUATOR JACK LUN 7072	28	1984	new
656	FLAPS ACTUATOR JACK LUN 7072	3	1984	repairs needed
657	AERODYNAMIC BRAKE JACK LUN 7073	93	1984	new
658	AERODYNAMIC BRAKE JACK LUN 7073	5	1984	repairs needed
659	BRAKE JACK SU 5500-2020 E	3	1984	new
662	LH MAIN UNDERCARRIAGE JACK LUN 7141	1	1984	repairs needed
663	NOSE GEAR ACTUATOR JACK LUN 7140(7131)	2	1984	new
664	NOSE GEAR ACTUATOR JACK LUN 7140(7131)	1	1984	repairs needed
665	RH MAIN UNDERCARRIAGE JACK LUN 7142	4	1984	new
666	RH MAIN UNDERCARRIAGE JACK LUN 7142	4	1984	repairs needed

667	LH MAIN UNDERCARRIAGE JACK LUN 714-6 (7142)	6	1984	new
668	NOSE GEAR LOCK JACK SU-400-3-6-35	11	1984	new
669	NOSE GEAR LOCK JACK SU-400-3-6-35	1	1984	repairs needed
670	MAIN UNDERCARRIAGE JACK LUN 7132	19	1984	new
671	WORKING JACK LUN 7132	24	1984	new
672	WORKING JACK LUN 7132	3	1984	repairs needed
673	JACK LUN 7182 set x 2 ea.	6	1984	new
674	LH JACK LUN 7182	12	1984	new
675	LEG TRAP DOOR JACK LUN 7102 set x 2 ea.	25	1984	new
676	LEG TRAP DOOR JACK LUN 7102 set x 2 ea.	5	1984	repairs needed
677	LEG TRAP DOOR JACK LUN 7102-2	4	1984	new
678	TRAP JACK LUN 7102	22	1984	new
679	TRAP JACK LUN 7102	2	1984	repairs needed
680	UNDERCARRIAGE DOOR JACK LUN 7102-01	7	1984	new
681	JACK VM 0605820A	2	1984	new
682	VOLTAMPERE-METER LUN 2742	5	1979	repairs needed